




INSTALL AND TRENCH IN SHOREFLEX AT OPENING OF CULVERT OUTFALL. DEPTH AND LENGTH OF TRENCH SHOULD BE DETERMINED BY ENGINEER AND BACKFILLED WITH 4000 PSI CONCRETE.




TRENCHED IN A MIN. OF 6" OR 1 BLOCK, FOR ALL EDGES NOT EXPOSED TO FLOW



OVERLAP DETAIL PERPENDICULAR TO WATER FLOW



CONCRETE ABUTMENT ANCHOR TRENCH



GENERAL NOTES:

- ANCHOR TRENCHES IN HIGH FLOW AREAS SHOULD HAVE NON-ERODIBLE BACKFILL.

Drawing N.T.S.



Project:	
Customer:	
Detail Title:	ShoreFlex Existing Outfall

DISCLAIMER
 THE INFORMATION CONTAINED HEREIN HAS BEEN COMPILED BY SHORETEC® LLC AND TO THE BEST OF OUR KNOWLEDGE, ACCURATELY REPRESENTS THE SHOREFLEX® PRODUCT USE IN THE APPLICATIONS WHICH ARE ILLUSTRATED. FINAL DETERMINATION OF THE SUITABILITY FOR THE USE CONTEMPLATED AND ITS MANNER OF USE ARE THE SOLE RESPONSIBILITY OF THE USER. STRUCTURAL DESIGN AND ANALYSIS SHALL BE PERFORMED BY THE QUALIFIED ENGINEER.